

INSTRUCTION MANUAL FOR 3¹¹/₁₆" TO 6" BORE DODGE® SPECIAL DUTY BEARINGS

LUBRICATION INSTRUCTIONS

Storage or Special Shutdown—If exposed to wet or dusty conditions or to corrosive vapors, extra protection is necessary: Add grease until it shows at the seals; rotate the bearing to distribute grease; cover the bearing. After storage or idle period, add a little fresh grease before running.

High Speed Operation—In the higher speed ranges too much grease will cause overheating. The amount of grease that the bearing will take for a particular high speed application can only be determined by experience—see "Operating Temperature." If excess grease in the bearing causes overheating, it will be necessary to remove grease fitting (also drain plug when furnished) to permit excess grease to escape. The bearing has been greased at the factory and is ready to run. When establishing a relubrication schedule, note that a small amount of grease at frequent intervals is preferable to a large amount at infrequent intervals.

Operation in Presence of Dust, Water or Corrosive Vapors—Under these conditions the bearing should contain as much grease as speed will permit, since a full bearing with consequent slight leakage is the best protection against entrance of foreign material. In the higher speed ranges too much grease will cause overheating—see "High Speed Operation" above. In the lower speed ranges it is advisable to add extra grease to a new bearing before putting into operation. Bearings should be greased as often as necessary (daily if required) to maintain a slight leakage of the seals.

Average Operation—This bearing has been greased at the factory and is ready to run. The following table is a general guide for relubrication. However, certain conditions may require a change of lubricating periods as dictated by experience. See "High Speed Operation" and "Operation in Presence of Dust, Water or Corrosive Vapors" above.

Operating Temperature—Abnormal bearing temperature may indicate faulty lubrication. Normal temperature may range from "cool to warm to the touch" up to a point "too hot to touch for more than a few seconds," depending on bearing size and speed, and surrounding conditions. Unusually high temperature accompanied by excessive leakage of grease indicates too much grease. High temperature with no grease showing at the seals, particularly if the bearing seems noisy, usually indicates too little grease. Normal temperature and slight showing of grease at the seals indicate proper lubrication.

Lubrication Guide

Read Preceding Paragraph Before Establishing Lubrication Schedule.

| HOURS Run per Day | Suggested Lubrication Period in Weeks | | | | |
|-------------------------|---------------------------------------|----------------------|----------------------|-----------------------|------------------------|
| | 1 to 250 RPM | 251 to 500 RPM | 501 to 750 RPM | 751 to 1000 RPM | 1001 to 1250 RPM |
| 8 | 12 | 12 | 10 | 7 | 5 |
| 16 | 12 | 7 | 5 | 4 | 2 |
| 24 | 10 | 5 | 3 | 2 | 1 |

Kind of Grease—Many ordinary cup greases will disintegrate at speeds far below those at which DODGE bearings will operate successfully if proper grease is used. DODGE bearings up to and including 5 shaft sizes have been lubricated at the factory with an NLGI #2 lithium complex base grease. DODGE bearings greater than 5 shaft size have been lubricated with an NLGI #2 EP additive lithium base grease. Relubricate with lithium or lithium complex base grease, or a grease which is compatible with the original lubricant and suitable for roller bearing service. In unusual or doubtful cases the recommendation of a reputable grease manufacturer should be secured.

Special Operating Conditions—Refer acid, chemical, extreme or other special operating conditions to RELIANCE INDUSTRIAL COMPANY, Greenville, SC 29602.

WARNING: Because of the possible danger to persons(s) or property from accidents which may result from the improper use of products, it is important that correct procedures be followed. Products must be used in accordance with the engineering information specified in the catalog. Proper installation, maintenance and operation procedures must be observed. The instructions in the instruction manuals must be followed. Inspections should be made as necessary to assure safe operation under prevailing conditions. Proper guards and other suitable safety devices or procedures as may be desirable or as may be specified in safety codes should be provided, and are neither provided by Baldor Electric Company nor are the responsibility of Baldor Electric Company. This unit and its associated equipment must be installed, adjusted and maintained by qualified personnel who are familiar with the construction and operation of all equipment in the system and the potential hazards involved. When risk to persons or property may be involved, a holding device must be an integral part of the driven equipment beyond the speed reducer output shaft.



BALDOR

World Headquarters
P.O. Box 2400, Fort Smith, AR 72902-2400 U.S.A., Ph: (1) 479.646.4711, Fax (1) 479.648.5792, International Fax (1) 479.648.5895
Dodge Product Support
6040 Ponders Court, Greenville, SC 29615-4617 U.S.A., Ph: (1) 864.297.4800, Fax: (1) 864.281.2433
www.baldor.com



**Parts for
3¹¹/₁₆" to 6" Bore
Special Duty
Bearings
(3¹¹/₁₆"-5"
Size Shown)**

NOTE: The two-digit numbers are for reference only. Order parts by the six-digit numbers in the Parts List. Each six-digit number is a complete identification of the part or assembly.



| Reference | Name of Part | Quantity Required for One Assembly | | | | | | | Part Numbers for Various Shaft Sizes | | | |
|-----------|---|------------------------------------|------------------|--------|----------|----------|--------------------|---------------------|--------------------------------------|---|--------------------------------------|-------------------------------------|
| | | N-E Pillow Block | Exp. Pillow lock | D Unit | S-1 Unit | B-1 Unit | N-E Flange Bearing | Exp. Flange bearing | 3 ¹¹ / ₁₆ to 4 | 4 ⁷ / ₁₆ to 4 ¹ / ₂ | 4 ¹⁵ / ₁₆ to 5 | 5 ⁷ / ₁₆ to 5 |
| 11 | Lubrication Fitting | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 405015 | 405015 | 405015 | 405015 |
| 12 | Non-Expansion Lubrication Stud | 1 | .. | 1 | .. | 1 | 1 | .. | 405013 | 405013 | 405013 | 401013 |
| 14 | Expansion Lubrication Stud | .. | 1 | .. | 1 | .. | .. | 1 | 405011 | 405011 | 405011 | 405011 |
| 24 | 4-Bolt Non-Expansion Pillow Block Housing | 1 | .. | .. | .. | .. | .. | .. | 066716 | 066722 | 066728 | 066734 |
| 34 | 4-Bolt Expansion Pillow Block Housing | .. | 1 | .. | .. | .. | .. | .. | 066719 | 066725 | 066731 | 066737 |
| ♠ | Flange Housing Shims | .. | .. | .. | .. | .. | 6 | 6 | 427310 | 427311 | 427315 | 427317 |
| ♠ | 4-Bolt Non-Expansion Pillow Block Housing Shims | 6 | .. | .. | .. | .. | .. | .. | 427243 | 427244 | 427245 | 427246 |
| ♠ | 4-Bolt Expansion Pillow Block Housing Shims | .. | 6 | .. | .. | .. | .. | .. | 427283 | 427284 | 427285 | 427286 |
| 53 | Timken Cup | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 390704 | 390707 | 390710 | 390713 |
| 54 | Timken Cone | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 390705 | 390708 | 390711 | 309712 |
| 55 | Adjustment Nut | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 066037 | 066041 | 066045 | 065468 |
| 56 | Adjustment Nut Lockscrew | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 400530 | 400530 | 400530 | 400532 |
| 57 | Adapter Nut | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 066038 | 066042 | 066046 | 065472 |
| 60 | Piston Ring | 4 | 4 | 4 | 4 | 4 | 4 | 4 | 410038 | 410040 | 410042 | 410044 |
| 64 | Adapter Nut Lockscrew | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 400154 | 400158 | 400162 | 400198 |
| 70 | Non-Expansion Inner Housing | 1 | .. | 1 | .. | .. | 1 | .. | 066036 | 066040 | 066044 | 065467 |
| 80 | Expansion Inner Housing | .. | 1 | .. | 1 | .. | .. | 1 | 066074 | 066076 | 066078 | 065482 |
| ♠ | B-1 Unit Housing | .. | .. | .. | .. | 1 | .. | .. | 066100 | 066101 | 066103 | 066104 |
| ♠ | Non-Expansion Flange Bearing Housing | .. | .. | .. | .. | .. | 1 | .. | 104292 | 104298 | 104304 | 104314 |
| ♠ | Expansion Flange Bearing Housing | .. | .. | .. | .. | .. | .. | 1 | 104295 | 104301 | 104307 | 104317 |

| Reference | Name of Part | Part Numbers for Various Shaft Sizes | | | | | | | | | | | |
|-----------|-----------------------|--------------------------------------|-------------------------------|-------------------------------|---------------------------------|--------|--------------------------------|-------------------------------|---------------------------------|--------|--------------------------------|---------------------------------|--------|
| | | 3 ¹¹ / ₁₆ | 3 ³ / ₄ | 3 ⁷ / ₈ | 3 ¹⁵ / ₁₆ | 4 | 4 ⁷ / ₁₆ | 4 ¹ / ₂ | 4 ¹⁵ / ₁₆ | 5 | 5 ⁷ / ₁₆ | 5 ¹⁵ / ₁₆ | 6 |
| 13 | Lubrication Cover ▲ ‡ | 405063 | 405063 | 405063 | 405063 | 405063 | 405063 | 405063 | 405063 | 405063 | 405043 | 405043 | 405043 |
| | N-E Name Plate ▲ ‡ | 412148 | 412148 | 412148 | 412148 | 412148 | 412148 | 412148 | 412148 | 412148 | 412148 | 412148 | 412148 |
| | Exp. Name Plate ▲ ‡ | 403950 | 403950 | 403950 | 403950 | 403950 | 403950 | 403950 | 403950 | 403950 | 403950 | 403950 | 403950 |
| 51 | Adapter ▲ | 066139 | 066140 | 066141 | 066039 | 066142 | 066043 | 066145 | 066047 | 066148 | 065441 | 065442 | 065443 |

Note: N-E is Non-Expansion & Exp. is Expansion type.

♠ Not shown on drawing.

▲ One required.

‡ Not furnished with pillow block or flange bearing unless specified.

INSTALLATION INSTRUCTIONS

WARNING

To ensure that drive is not unexpectedly started, turn off and lock out or tag power source before proceeding. Failure to observe these precautions could result in bodily injury.

TO LOCATE BEARINGS ON SHAFT—

1. Shaft should be within commercial tolerances, straight, smooth and clean. Apply a light coating of oil or other rust inhibitor to the shaft in the bearing area.
2. Loosen lockscrews 64 in adapter nuts 57 to prevent damage to adapter 51. (If necessary to expand adapter 51, loosen adapter nut 57 at closed end of housing approximately two turns and tap on end of this nut.) Apply silicone sealant to the split in the adapter sleeve. This provides protection against contaminants.
3. Slide bearing on shaft and locate where wanted.
4. **Do not bolt outer housing to support until bearing is tightened on shaft.**
5. **Block up shaft to remove weight from bearing.** This is extremely important where the bearing and shaft are large; also, where heavy equipment is mounted on shaft.




Figure 1 – Preferred Method – Hitting directly on face of adapter nut, with brass bar parallel to shaft, while applying torque with barring rod to tighten nut. ▲▲




Figure 2 – Hitting on nut at an angle where unable to hit at right angle to face. This method is not as effective as the method shown in Figure 1. ▲▲




Figure 3 – Hitting on O.D. of nut with brass bar held at right angle to shaft. This method is not as effective as the methods shown in Figures 1 or 2. ▲▲




Figure 4 – This is an alternate method to those shown in Figures 1, 2 and 3 in that a spanner wrench is used in place of the barring rod. ▲▲

▲ For $3\frac{1}{2}$ and smaller shaft sizes the brass bar should not be less than 1" diameter; for $3\frac{15}{16}$ " to 5" shaft sizes not less than $1\frac{1}{4}$ " diameter; for $5\frac{7}{16}$ " to 7" shaft sizes not less than $1\frac{1}{2}$ " diameter, for $7\frac{1}{2}$ " to 10" shaft sizes not less than 2" diameter.

▲ A 12" length of drill rod which is $\frac{1}{64}$ " less in diameter than the barring pockets is

TO TIGHTEN BEARING ON SHAFT—

6. Loosen (turn counter-clockwise 2 or 3 turns) adapter nut 57 at open end of housing (adjustment nut end).
7. Tighten (turn clockwise) adapter nut 57 at closed end of housing (end with instruction plate on inner housing). Check other nut periodically to see that it is loose as in Step 6. Make sure this nut does not touch end of bearing cone 54 during tightening operation. (See Arrow "A" on Drawing.)

When considerable effort is required to turn adapter nut 57, use sledge and brass bar as shown in illustrations. Keep tightening nut with barring rod or spanner wrench while hitting on brass bar.

The adapter nut is nearly tight when a solid sound or ring, such as made by hitting directly on the end of a solid shaft, develops in the adapter nut. If possible, tighten more by hitting on the barring rod or spanner wrench and the brass bar simultaneously.

Notice:

When installing the bearing, it is very important that the split tapered adapter (bearing sleeve) be drawn down on the shaft as tight as possible. Use one of the following illustrated methods to overcome friction between the tapered adapter and the taper-bored cone and between the threads of the adapter and the adapter nut. The sudden jar developed by the sledge

recommended for use as barring rod. Pipe should be used as shown for additional leverage.

■ Pin in spanner wrench should be $\frac{1}{64}$ " less in diameter than the barring pockets.

and brass bar (while the tightening force is being applied to the adapter nut) helps to overcome the friction, allowing the nut to be tightened to a greater degree than otherwise possible.



8. If possible, line up one lockcrew hole in adapter nut with a slot in end of adapter. If adapter nut can no longer be tightened, do not back off to line up with slot in adapter 51.
9. Tighten (turn clockwise) adapter nut 57 at open end of housing until it is snug against end of bearing cone 54. (See arrow "A" on drawing.) Tighten lockcrew 64 in this nut onto shaft or onto adapter 51.
10. Check hold-down bolts in outer housing to see they are loose and free. (If too tight, an excessive thrust load could be imposed on bearing.) If bolts are very tight, it may be advisable to loosen adapter to move slightly on shaft.
11. **Expansion Bearing:** Loosen the cap bolts in outer housing a little so unit is free to align. Inner unit should be located with unit housing in center of outer housing so unit can move freely in either direction. Do not remove shims between cap and base of outer housing. Tighten hold-down bolts. **Non-expansion Bearing:** Loosen cap bolts in outer housing a little so unit is free to align in outer housing. Tighten hold-down bolts. Retighten cap bolts on both expansion and non-expansion bearing.
12. After a short run make sure adapter 51 is tight as follows: loosen lock screws 64; loosen hold-down bolts; perform steps 5 to 11 inclusive.

REMOVAL INSTRUCTIONS

1. Loosen lockcrew 64 in both adapter nuts 57 and loosen hold-down bolts. Block up shaft to remove weight from bearing.
2. Loosen (turn counterclockwise) adapter nut 57 at closed end of housing approximately two turns.
3. Tighten (turn clockwise) nut 57 at open end of housing. Use sledge and brass bar as in Fig. 4 to break the cones loose on the adapter, thus allowing the adapter to loosen on shaft.

UNIT REPLACEMENT INSTRUCTIONS

1. Remove bearing from shaft per removal instructions.
2. Match mark cap and base of each outer housing before removing cap.
3. Fit each unit to its outer housing before putting on shaft.
4. Add or remove shims between cap and base as required to obtain "snug" fit of unit in outer housing with cap bolts drawn down securely.
5. Check fit by prying against lubrication stud in unit through the lubrication hole in housing cap with a screw driver or small pinch bar depending upon the size of the pillow blocks.
6. The "snug" fit becomes a matter of judgment. A "loose or sloppy" fit may allow a unit mount to move in its outer housing thus wearing the mating surfaces. Too "tight" a fit will not allow the unit to move and compensate for misalignment and for shaft deflection caused by belt pull and dead weight.
7. When reassembling pillow blocks make sure match marks (step 2) on cap and bases match.



(5⁷/₁₆-6 Size Shown)

Table 1 – Cap Bolts Torque (Pillow Blocks)

| Size | Cap Bolts | | | Hold-down Bolts |
|--|-----------|----------------------------------|-----------------|-----------------|
| | Qty. | Size | Torque Ft.-Lbs. | |
| 3 ¹¹ / ₁₆ -4 N-E & Exp. | 2 | 1 ¹ / ₈ -7 | 350 | 4 |
| 4 ⁷ / ₁₆ -4 ¹ / ₂ N-E | 4 | 7/8-9 | 170 | 4 |
| 4 ⁷ / ₁₆ -4 ¹ / ₂ Exp. | 2 | 1 ¹ / ₈ -7 | 350 | 4 |
| 4 ¹⁵ / ₁₆ -5 N-E | 4 | 1-8 | 250 | 4 |
| 4 ¹⁵ / ₁₆ -5 Exp. | 2 | 1 ¹ / ₄ -7 | 500 | 4 |
| 5 ⁷ / ₁₆ -6 N-E & Exp. | 4 | 1-8 | 250 | 4 |

Table 2 – Cap Bolts Torque (Flanges)

| Size | Cap Bolts | | |
|--|-----------|----------------------------------|-----------------|
| | Qty. | Size | Torque Ft.-Lbs. |
| 3 ¹¹ / ₁₆ -4 ¹ / ₂ | 2 | 1-8 | 250 |
| 4 ¹⁵ / ₁₆ -5 | 4 | 1-8 | 250 |
| 5 ⁷ / ₁₆ -6 | 2 | 1 ¹ / ₄ -7 | 500 |